

SAMMYS®

Threaded Rod Anchoring System

When Every Second Counts, Reach for the Sammy X-Press Drill/Drive® Anchor

Sammy X-Press Drill/Drive Anchors are designed to fasten threaded rod to metal deck or purlin when access to the back of the substrate is limited, and eliminates the need to build costly trapeze supports, saving hours of labor each day. With a fresh drill bit on each installation, Drill/Drive Anchors take the speed of installing Sammy X-Press® to the next level.



Sammy X-Press Drill/Drive Time Savings

	Sammy X-Press Drill/Drive	Sammy X-Press	Trapeze Support
Installation Time Per Fastener	9 seconds <ul style="list-style-type: none">• No dull drill bits• No need to change out drill bits• No need to search for drill bits• No strut or clamp required	45 seconds <ul style="list-style-type: none">• No strut required• No clamp required	30 minutes <ul style="list-style-type: none">• Cut strut to desired length• Attach clamps
Total # of Hours to Install 100 anchors	.25 hours	1.25 hours	50 hours
Total # of Hours to Install 1,000 anchors	2.50 hours	12.50 hours	500 hours



X-Press Drill/Drive Anchor

Part #: 8151957
Model #: XPDD 40

X-Press It 2.0 Installation Tool

Part #: 8196910
Model #: UXPIT2.0



Learn More

www.sammysanchors.com